


۲

KONE REMOTECALL[™]

Smartphone application user interface for elevators with destination control system (KONE Destination)

KONE RemoteCall is an innovative mobile application for smartphones. It allows users to make personalized elevator calls quickly and conveniently from anywhere in the building. It is available for mobile phones using the latest iOS iPhone and Android operating systems.

۲



KEY BENEFITS

Mobility

 Users can place a call from anywhere in the building at any time

horter waiting time

Reduces waiting times and eases lobby congestion

Personalization

 Three different call types can be preprogrammed – normal, priority and accessibility

User friendly

- Clear, intuitive interface is easy to use
- Favorite or frequently used routes can be saved for quick selection

Access control

۲

- Improves access control, with only allowed destination floors listed
- User profiles and access rights are easily managed via separate software


۲

MAKING AN ELEVATOR CALL WITH KONE REMOTECALL


When the KONE RemoteCall application is opened, the recent and favorite elevator calls are displayed. The user makes the elevator call and the letter of the allocated elevator is displayed. If the desired elevator call is not listed in the favorites view, the user can make the needed elevator call by first selecting the departure floor and then the destination floor. The call can then be added as a favorite if desired.

۲


List user interface












Slider user interface



۲



2. User indicates destination floor



3. Elevator call is processed



4. Allocated elevator is displayed

Smith John

User information screen

Û



5. Arrival of the elevator is indicated

Smith John

Floors

Devices

(î)

N

П

۲

MANAGING KONE REMOTECALL IN YOUR BUILDING

KONE People Flow Manager software allows you to easily create and manage user accounts:

- Add or remove users
- View all users

1. User indicates

departure floor

- View and edit information for particular users
- Manage floor access rights
- Set call type (normal destination, priority, disability)





www.kone.com



۲